



111 Lehigh Street Macungie, Pa. 18062 Phone: 610-966-3484 Fax: 610-965-5743

SURFACE MOUNTING ACCESSORIES

GENERAL INSTRUCTIONS FOR DRILLING WALL MOUNTING HOLES

ACCESSORY

TOWEL BAR ENDS

TOWEL RING

ROBE HOOD

TOILET PAPER HOLDER

SOAP DISH

TOOTHBRUSH HOLDER

TUMBLER HOLDER

ON EACH ACCESSORY IN THE ABOVE RANGE THERE ARE TWO SMALL "DIMPLES" WHICH PROVIDE WALL MOUNTING HOLE DRILLING LOCATIONS. USING THESE "DIMPLES" FOR LOCATION DRILL THRU THE PART WITH A 3/16 INCH DIAMETER DRILL AND FOLLOW WITH A SUITABLE COUNTERSINK TO ACCOMMODATE #8 BY 1 1/2 INCH OVAL HEAD SCREWS.

RECOMMENDED DRYWALL AND LATH AND PLASTER INSTALLATION

PLACE THE ACCESSORY IN THE DESIRED POSITION AND MARK THE WALL THRU THE MOUNTING HOLES IN THE ACCESSORY. USING A 3/16 INCH DIAMETER DRILL MAKE 2 HOLES 1 INCH DEEP IN THE WALL. INSERT THE PLASTIC WALL ANCHORS IN PLACE FLUSH WITH THE WALL SURFACE. WIPE A FILM OF CLEAR SILICONE OVER THE MOUNTING SURFACE OF THE ACCESSORY AND POSITION THE ACCESSORY ON THE WALL ENSURING THAT THE MOUNTING

HOLES CORRESPOND WITH THE POSITIONS OF THE ANCHORS. INSERT THE #8 BY 1 1/2 INCH SCREWS AND SCREW IN PLACE. WITH A DAMP CLOTH REMOVE ANY SURPLUS SILICONE WHICH MAY HAVE BEEN SQUEEZED OUT AROUND THE EDGE OF THE ACCESSORY DURING TIGHTENING OF THE SCREWS.