



111 Lehigh Street Macungie, Pa. 18062 Phone: 610-966-3484 Fax: 610-965-5743

INSTALLATION INSTRUCTIONS FOR NEOANGLE SHOWER BASE

THE SIMPLEST TO INSTALL BECAUSE THERE ARE ONLY TWO SIZES AGAINST THE WALL.

1. THE SHOWER BASE IS MEANT TO BE INSTALLED WITH THE WATER DAM IN CONTACT WITH THE STUDS OR FRAMING. INSTALL PRE DRYWALL OR CUT DRYWALL TO ACCEPT SHOWER BASE.

2. MEASURE OFF FROM WALL WHERE DRAIN SHOULD GO, CUT HOLE IN FLOOR TO ACCEPT DRAIN.

3. LAY SHOWER BASE IN PLACE AND CHECK LEVEL AT TOP OF SHOWER BASE AND MIX MORTAR AND SAND, PUT ENOUGH MIX ON FLOOR TO LEVEL BASE AND WIGGLE SHOWER BASE AROUND UNTIL ITS DOWN TO THE SHIMS. BASE SHOULD BE SUPPORTED EVENLY AND NOT WIGGLE WHEN YOU STEP ON IT.

4. WHEN THE MORTAR IS DRY REMOVE SHIMS.